



ZEBRA HIBC in GS1 KONFIGURACIJA:



ZEBRA klasična nastavitev, namesto tipkovnice:



Honeywell HIBC in GS1 KONFIGURACIJA:



Honeywell klasična nastavitev, namesto tipkovnice:

